



EZDown Instruction Kit

FIAT FULL BACK – ED2000

www.ezdown.co.za

1

Remove cables or metal bars 1st left hand side then proceed to RHS

2

Use this hole in the tailgate for the cable stud ED0054

Remove the entire bracket and their cable

3

End fitting of cable side view

Swage

Cable

NB !! When fitting the cable make sure the swage on cable's end fitting is facing away from the metal body of vehicle so it does not interfere with metal body of vehicle and scratch paintwork

4

Right Hand Side

5

5,0

K

6

9,0

L

7

8

PUTTING IT INSIDE THE TAILGATE PANEL USING THE METAL HANDLE THEN BREAKING THE HANDLE OFF AFTER BY TWISTING THE METAL OFF

A

9

FROM INSIDE THE TAILGATE PANEL

A

C

10

FROM OUTSIDE THE TAILGATE PANEL

C

11

FROM OUTSIDE THE TAILGATE PANEL

C

F

J

L

E

12

NB: After installation please close tailgate gently to ensure that there is no interference with any hardware.

FITTING KIT CODE	MANUFACTURER	MODEL TYPE	YEAR	STOCKIST	PRODUCT	REVISION	LABOUR TIME	DATE	PAGE
ED2000	FIAT	FULL BACK	2017	DEALERSHIPS	EZDOWN	4	30min	14/07/2017	1
TORQUE-N.m	★ 27N.m±2N.m			★ 27N.m±2N.m			★ 15N.m±2N.m		

IMPORTANT: No liability will be incurred by Industrial Specialised Applications company, for injury, death, or property damage caused by a product which has been set up, operated, and/or installed contrary to EZDown installation guide/manual, or which has been subjected to misuse, negligence, or accident, or which has been repaired or altered by anyone other than Industrial Specialised Applications, or which has been used in a manner or for a purpose for which the product was not designed.